



eers™



Custom-Fitted Earphones

For your eers™ only! | SonoFit™

Since ears are more unique than fingerprints, perfect fit and comfort can only be achieved with custom-fitting earpieces. Sonomax has developed an instant, self-fit custom earpiece system that can be done on the spot by the consumer.

SonoFit™ is the engineering innovation and delivery system at the heart of this technology. It allows the user to create a pair of custom-fitted earphones in a simple 5-minute process. SonoFit™ consists of patented earpieces; inflation pumps filled with medical-grade silicone, all bundled into a simple headband. The strategically-designed snap assembly headband and many of the pump components are manufactured from either recyclable thermoplastics or metals.

This multi-patented technology can be summarized with the following unique features:

- The earpieces are surrounded by a medical-grade silicone bladder into which the liquid silicone is injected. While highly robust for safety, the bladder is also able to conform to shape and size of any ear canal. Liquid silicone is always contained within the bladder and never touches the ear canal. The bladders are 100% tested to ensure ultimate safety.
- The activation tabs were engineered to be user intuitive with a simple locking mechanism and single activating switch to initiate the inflation process, while maintaining durability.
- The pump system has been designed to deliver the optimal volume of silicone for every earpiece providing a custom-fitted plug appropriately-sized and shaped. Liquid silicone is injected at a very gradual, safe and comfortable rate providing relaxing experience that fully cures in 5 short minutes.
- The earpiece connectors provide a hermetic seal between the pumps and the earpiece. This allows for perfect secure earpiece expansion and the dual function interface allows the earpieces to be easily removed from the SonoFit™ system after the fitting is complete.

SonoFit™ provides the user with their own pair of custom-fitted earpieces, made just for their ears, with a **guaranteed perfect fit!**

The SonoFit™ Fitting Experience



SonoFit™ Position

Gently position The SonoFit™ Custom Fitting System on your head and adjust it to your ears.



5 Minute Set

Wait only 5 minutes for the silicone to safely form to your ears' unique shape.



Complete!

Simply detach the earphones from the SonoFit™ System, attach the faceplates, and your custom-fitted earphones are ready!



1-888-921-eers
www.sculptedeers.com



8375 Mayrand - Montreal, Quebec
H4P 2E2 Canada - 514.932.2674
www.sonomax.com